

## **Indoor Installation Instructions for JennFrame6**

1. Take all pieces out of the box and off pallet.
2. Lay out all the pieces on the ground.
3. Arrange them the way that they will eventually be set.
4. Find the six foot top beam. Slide the top pole into the two end frame fittings and tighten the set screws. Slide two galvanized leg poles into each end of the end frame fitting.
5. Tighten the bolts with nuts on each side of the end frame fitting.
6. Attach the 2 SH114 swing hangers around the top beam. The first swing hanger should be attached two feet from the end of the end frame fitting, the second should be attached two feet from the first hanger.
7. Attach the Optional JennSwing Frame Feet to prevent marring on floor surfaces. Before setting swing set upright, take four feet and hit with a hammer until feet fit snugly into the bottom of the pipe.

### **To attach strap swing seat with coated chain:**

1. Using the wrench open the shackle pendulum on the swing hanger and attach the silver end of the chain to the shackle.
2. Tighten the tamper head bolt, using the wrench, so that the bolt is tight.
3. Attach the small end of an h shackle to the coated part of the chain. You will need to force the bolt through the coated part.
4. Again, tighten the tamper proof bolt with the wrench.
5. Attach the longer end of the h shackle to the triangle end of the swing seat, again using the wrench to close and tighten the bolt.
6. Repeat this process for the other side of the swing.

### **To attach Jennswing:**

1. Using the wrench open the shackle pendulum on the swing hanger and attach the silver end of the chain to the shackle.
2. Tighten the tamper head bolt, using the wrench, so that the bolt is tight.
3. Repeat this process for the other side of the swing.
4. The incline of the Jennswing can be adjusted by removing the shackle where the straight piece of chain attaches to the V portion of the chain. By attaching the straight piece of chain to different links on the V portion of the chain the incline can either be made straighter or flatter, depending upon your child's needs.
5. Also, the harness has several straps that can be adjusted to suit you child's support needs.

**NOTE:** Set swing set up on a flat smooth surface

**NOTE:** Our above ground swing frames are not designed for vigorous swinging. They are designed for swinging within the "A" of the frames.

**NOTE:** The weight limit of the person per frame is 250 pounds. This is in addition to the weight of the item being hung. However, as you increase the weight of the person, you decrease the swinging motion.